



INSTALLATION GUIDE


AXIS F4005-E Dome Sensor Unit




1x





1x




1x







1x






1







4




5




6




7



8



i



Installation Guide

AXIS F4005-E Dome Sensor Unit

© Axis Communications AB, 2015

Ver.1.0

Printed: March 2015

Part No. 62154